

お役に立つ付録 (SLAVE MODULE)

| VME J1/P1 | | | | VME J2/P2 | | | | |
|-----------|-----|----------|------|-----------|------------|------|-----|-----------|
| 端子番号 | 列 | ニーマニック | 端子番号 | 列 | ニーマニック | 端子番号 | 列 | ニーマニック |
| 1 | A1 | D00 | 33 | B1 | BBSY* | 65 | C1 | D08 |
| 2 | A2 | D01 | 34 | B2 | BCLR* | 66 | C2 | D09 |
| 3 | A3 | D02 | 35 | B3 | ACFAIL* | 67 | C3 | D10 |
| 4 | A4 | D03 | 36 | B4 | BG0IN* | 68 | C4 | D11 |
| 5 | A5 | D04 | 37 | B5 | BG0OUT* | 69 | C5 | D12 |
| 6 | A6 | D05 | 38 | B6 | BG1IN* | 70 | C6 | D13 |
| 7 | A7 | D06 | 39 | B7 | BG1OUT* | 71 | C7 | D14 |
| 8 | A8 | D07 | 40 | B8 | BG2IN* | 72 | C8 | D15 |
| 9 | A9 | GND | 41 | B9 | BG2OUT* | 73 | C9 | GND |
| 10 | A10 | SYSCLK | 42 | B10 | BG3IN* | 74 | C10 | SYSFAIL* |
| 11 | A11 | GND | 43 | B11 | BG3OUT* | 75 | C11 | BERR* |
| 12 | A12 | DS1* | 44 | B12 | BR0* | 76 | C12 | SYSRESET* |
| 13 | A13 | DS0* | 45 | B13 | BR1* | 77 | C13 | LWORD* |
| 14 | A14 | WRITE* | 46 | B14 | BR2* | 78 | C14 | AM5 |
| 15 | A15 | GND | 47 | B15 | BR3* | 79 | C15 | A23 |
| 16 | A16 | DTACK* | 48 | B16 | AM0 | 80 | C16 | A22 |
| 17 | A17 | GND | 49 | B17 | AM1 | 81 | C17 | A21 |
| 18 | A18 | AS* | 50 | B18 | AM2 | 82 | C18 | A20 |
| 19 | A19 | GND | 51 | B19 | AM3 | 83 | C19 | A19 |
| 20 | A20 | IACK* | 52 | B20 | GND | 84 | C20 | A18 |
| 21 | A21 | IACKIN* | 53 | B21 | SERCLK(1) | 85 | C21 | A17 |
| 22 | A22 | IACKOUT* | 54 | B22 | SERDAT*(1) | 86 | C22 | A16 |
| 23 | A23 | AM4 | 55 | B23 | GND | 87 | C23 | A15 |
| 24 | A24 | A07 | 56 | B24 | IRQ7* | 88 | C24 | A14 |
| 25 | A25 | A06 | 57 | B25 | IRQ6* | 89 | C25 | A13 |
| 26 | A26 | A05 | 58 | B26 | IRQ5* | 90 | C26 | A12 |
| 27 | A27 | A04 | 59 | B27 | IRQ4* | 91 | C27 | A11 |
| 28 | A28 | A03 | 60 | B28 | IRQ3* | 92 | C28 | A10 |
| 29 | A29 | A02 | 61 | B29 | IRQ2* | 93 | C29 | A09 |
| 30 | A30 | A01 | 62 | B30 | IRQ1* | 94 | C30 | A08 |
| 31 | A31 | -12V | 63 | B31 | +5V STDBY | 95 | C31 | +12V |
| 32 | A32 | +5V | 64 | B32 | +5V | 96 | C32 | +5V |

注意 J2/P2のA列とC列は使用者定義用です。

| TKO ANALOG CN | | | |
|---------------|-------|----|-------|
| 26 | GND | 25 | IND2* |
| 24 | GND | 23 | IND1* |
| 22 | RSVD | 21 | RESET |
| 20 | GATE3 | 19 | GATE2 |
| 18 | GATE1 | 17 | GATE0 |
| 16 | VBB | 15 | THRS |
| 14 | RSVD | 13 | RSVD |
| 12 | ALOGR | 11 | ALOGS |
| 10 | RSVD | 9 | RSVD |
| 8 | -5.4V | 7 | -5.4V |
| 6 | -8V | 5 | -8V |
| 4 | +8V | 3 | +8V |
| 2 | GND | 1 | GND |

| TKO DIGITAL CN | | | |
|----------------|--------|----|---------|
| 50 | GND | 49 | -15V |
| 48 | +15V | 47 | Q* |
| 46 | YSSIR* | 45 | DOIT* |
| 44 | F(3)* | 43 | F(2)* |
| 42 | F(1)* | 41 | F(0)* |
| 40 | GA(3)* | 39 | GA(2)* |
| 38 | GA(1)* | 37 | GA(0)* |
| 36 | BCAST* | 35 | SA(10)* |
| 34 | SA(9)* | 33 | SA(8)* |
| 32 | SA(7)* | 31 | SA(6)* |
| 30 | SA(5)* | 29 | SA(4)* |
| 28 | SA(3)* | 27 | SA(2)* |
| 26 | SA(1)* | 25 | SA(0)* |
| 24 | D(15)* | 23 | D(14)* |
| 22 | D(13)* | 21 | D(12)* |
| 20 | D(11)* | 19 | D(10)* |
| 18 | D(9)* | 17 | D(8)* |
| 16 | D(7)* | 15 | D(6)* |
| 14 | D(5)* | 13 | D(4)* |
| 12 | D(3)* | 11 | D(2)* |
| 10 | D(1)* | 9 | D(0)* |
| 8 | RSVD | 7 | RSVD |
| 6 | -5.4V | 5 | -5.4V |
| 4 | +5.2V | 3 | +5.2V |
| 2 | GND | 1 | GND |

注意 TOP IO BOTTOM IOは
使用者定義によります。

お役に立つ付録 (SLAVE MODULE)

| CAMAC | |
|----------------|-------|
| COMPONENT SIDE | |
| 端子番号 | 記号 |
| 86 | P1 |
| 84 | P2 |
| 82 | P3 |
| 80 | P4 |
| 78 | P5 |
| 76 | X |
| 74 | I |
| 72 | C |
| 70 | N |
| 68 | L |
| 66 | S1 |
| 64 | S2 |
| 62 | W24 |
| 60 | W22 |
| 58 | W20 |
| 56 | W18 |
| 54 | W16 |
| 52 | W14 |
| 50 | W12 |
| 48 | W10 |
| 46 | W8 |
| 44 | W6 |
| 42 | W4 |
| 40 | W2 |
| 38 | R24 |
| 36 | R22 |
| 34 | R20 |
| 32 | R18 |
| 30 | R16 |
| 28 | R14 |
| 26 | R12 |
| 24 | R10 |
| 22 | R8 |
| 20 | R6 |
| 18 | R4 |
| 16 | R2 |
| 14 | -12V |
| 12 | +200V |
| 10 | AQL |
| 8 | Y1 |
| 6 | +12V |
| 4 | Y2 |
| 2 | GND |

| CAMAC | |
|-------------|------|
| SOLDER SIDE | |
| 端子番号 | 記号 |
| 85 | B |
| 83 | F16 |
| 81 | F8 |
| 79 | F4 |
| 77 | F2 |
| 75 | F1 |
| 73 | A8 |
| 71 | A4 |
| 69 | A2 |
| 67 | A1 |
| 65 | Z |
| 63 | Q |
| 61 | W23 |
| 59 | W21 |
| 57 | W19 |
| 55 | W17 |
| 53 | W15 |
| 51 | W13 |
| 49 | W11 |
| 47 | W9 |
| 45 | W7 |
| 43 | W5 |
| 41 | W3 |
| 39 | W1 |
| 37 | R23 |
| 35 | R21 |
| 33 | R19 |
| 31 | R17 |
| 29 | R15 |
| 27 | R13 |
| 25 | R11 |
| 23 | R9 |
| 21 | R7 |
| 19 | R5 |
| 17 | R3 |
| 15 | R1 |
| 13 | -24V |
| 11 | -6V |
| 9 | ACN |
| 7 | E |
| 5 | +24V |
| 3 | +6V |
| 1 | GND |

| NIM STANDARD FUNCTION | |
|-----------------------|---------------------|
| 1 | +3V |
| 2 | -3V |
| 3 | |
| 4 | |
| 5 | COAXIAL PIN |
| 6 | COAXIAL PIN |
| 7 | COAXIAL PIN |
| 8 | +200V |
| 9 | |
| 10 | +6V |
| 11 | -6V |
| 12 | |
| 13 | CARRY #1 |
| 14 | |
| 15 | |
| 16 | +12V |
| 17 | -12V |
| 18 | |
| 19 | |
| 20 | |
| 21 | |
| 22 | |
| 23 | |
| 24 | |
| 25 | |
| 26 | |
| 27 | |
| 28 | +24V |
| 29 | -24V |
| 30 | |
| 31 | CARRY #2 |
| 32 | |
| 33 | 117V AC(HOT) |
| 34 | POWER RETURN GROUND |
| 35 | RESET |
| 36 | GATE |
| 37 | |
| 38 | COAXIAL PIN |
| 39 | COAXIAL PIN |
| 40 | COAXIAL PIN |
| 41 | 117V AC(NEUTRAL) |
| 42 | HIGH QUALITY GROUND |
| G | GROUND GUIDE PIN |

ご注意 ご使用のピンに付いている
コネクタピン及び電源をご確認ください